

# **Your Construction Pack**



**Celectricity** Bringing energy to your door

Electricity North West Limited, 304 Bridgewater Place, Birchwood Park, Warrington, WA3 6XG 01925 846 999 • www.enwl.co.uk Registered in England and Wales • Registered Number 2366949



## Top Tips to help you get ready on site

## Dn



## Use the correct duct specification

ENWL spec duct is always red and embossed 'DANGER ELECTRICITY CABLES' with no exceptions and should follow the spec documents provided in this pack.



### Make sure you source the correct meter housing & hockey stick

Meter housing should be sourced from approved suppliers; 500 – 800mm from bottom of box to finished ground level. Hockey stick must be white; situated on the left hand side and fitted so that the red elbow of duct does not protrude above ground level.



#### Ensure your duct is laid at the correct depth & prepared properly

Electricity North West Limited specification marker tape

Duct should be laid in accordance to the spec provided; with a minimum of 450mm from top of duct to top of finished surface with marker tape 100mm on top of the duct and minimum 300mm separation from other utilities. Full spec included is included with this construction pack.



### Book your meter installation with chosen supplier

As ENWL are not a supplier we cannot install your meter; we will provide the MPAN you need to book your meter fit. A full guide to metering is included with this construction pack.

Your MPAN will be sent to you separately within 5 working days

We cannot create your MPAN as we need more information from you – please see enclosed letter detailing our requirements

## Did you know?

We can supply your meter box and hockey stick at trade prices? We will even deliver free of charge - please let your planner know if you would like us to do this for you.

## **DON'T**

## **DO NOT** install black duct

ENWL cannot install any cables in black ducting. We will not be able to agree dates to connect your supply if black duct is in place; this can cause significant delays.

## **DO NOT** forget to book your metering

Once we have provided your MPAN you will need to book your metering (more info on page one & metering guide in this pack).

## **DO NOT** have obstructions on site

Scaffolding or other works on site can significantly delay your connection; please make sure you plan for your site to be clear for us to excavate and connect.

## Lastly don't forget we are here for you...

Your dedicated contact is

Our support team is also here should you need any advice or guidance 0800 195 4141 opt 2 opt 1